

# AM2CAM INSTALLATION DIAGRAM

If your factory (or aftermarket) reverse camera is powered on ignition and you would like to use the second camera input on your AM9X/AM10X then you will require an AM2CAM Input Switch Harness. The AM2CAM will only be required if you would like to add a second camera into the vehicle.

This is only applicable to AM9X/10X headunits with the two camera input support. You can check if your headunit supports this by checking if you have two icons for Camera R and Camera 2 on the home screen of the headunit.

To correctly utilise dual cameras for this head unit, connections to the AM2CAM are as follows:

Factory Camera Retention RCA to R Camera In RCA on AM2CAM

AM2CAM Camera Ground Cable (Black) to Camera Ground (Black) on 18 Pin Audio-Video Lead

AM2CAM R Camera 12V+ (Red) to R Camera 12V+ (Red) on 18 Pin Audio-Video Lead

AM2CAM Power 3.3v (Yellow) to RX on Audio-Video Lead (White)

Second Camera 12V+ connected to Camera 2 12V+ (Yellow) on 18 Pin Audio-Video Lead

Second Camera RCA connected to CAM2 RCA on 18 Pin Audio-Video Lead

