

USER MANUAL

Wire controlled Selfie Shutter Monopod

Model No: APSSB



CE FC

Version: V2.0

INTRODUCTION:

This is the monopod with a built-in Bluetooth controlled shutter function for smartphones. The max length of monopod can be extended over 1 meter. It has an indentation design along the metal rod to avoid smartphones turning down by weight or sudden movement. It is best used for travel and out-door use in taking photos or recording a movie clip with your smartphone or digital camera by yourself. With the assistance of the monopod, you can capture wider angle photos due to its length.

PRODUCT ILLUSTRATION:







PAIRING INSTRUCTIONS:

- 1) Switch on the button at the bottom of the handle. You will see a blue light indication.
- 2) Wait about 10 seconds and the blue light will start flashing, indicating that the device is in Bluetooth pairing status.
- 3) Switch on the Bluetooth on your smartphone and search for the device 'iselfie'
- 4) Depending on your smartphone, you may have to turn visibility on in order to connect to the monopod.
- 5) Select 'iselfie' in order to pair via Bluetooth. The blue flashing light indicator will stop after the pairing is successful.
- 6) Press the button on the rod to take a photo while using the Camera application on your smartphone.

Depending on your smartphones camera application, you may have to set the volume buttons on your smartphone to take a picture. This can be set in the camera settings of the application. An example of where to look is in the pictures below.





The reason for this is the monopod, presses the volume up button and takes a picture in order to make it compatible across different smartphones.

If you press the camera button on the monopod for 3 seconds, it will disable the Bluetooth pairing. In order to re-pair with the monopod, you will have turn it off then on and pair your smartphone with the monopod again through your Bluetooth settings.

- 7) It is possible that the first time pairing with the monopod may not be successful. Simply turn the monopod off then on and reconnect through the smartphone via Bluetooth's settings. If you are still having pairing issues, please restart your smartphone and try again.
- 8) If you would like to use the monopod again once it's switched off, you may have to re-pair the smartphone with the monopod via your Bluetooth's settings.
- 9) To un-pair your smartphone from the monopod to allow another smartphone to connect to it, please un-pair the monopod (iselfie) on your smartphone in the Bluetooth settings.
- 10) Switch off the monopod by switching off the button at the bottom of the handle.

SAFETY CAUTIONS AND MAINTENANCE:

- a) Do not charge the device with an unsuitable AC/DC power adaptor as it may be dangerous. The
 device must be charged properly by USB ports or by AC/DC adaptor with an input of
 AC100-240V,50-60Hz Output: DC 5V 500mA
- b) If you notice any overheating, strange noises or another strange anomaly, stop using the monopod and switch it off immediately.
- c) Do not drop the monopod on the floor/ground as it can become damaged and broken.
- d) Do not use abrasive cleaning solvents to clean the monopod.
- e) Do not place the device in the hot temperature or left inside a car under direct sunlight, as it can result in a malfunction.
- f) Do not expose the monopod with sharp objects as it will scratch and damage the monopod.
- g) Do not attempt to disassemble the monopod, as it does not contain serviceable components.
- h) If you do not use the monopod for a long period of time, be sure to store it in a dry place, free from extreme temperature, humidity and dust.

SAEFTY REMINDER

- a) Check your local laws regarding use or carry of this kind of device. Different states may have different regulations.
- b) Avoid use while driving or during any action sports as it may disturb your attention, and cause an accident.
- c) Never allow children to play with the monopod. Small parts may be a choking hazard.

BT SHUTTER Bluetooth version 3.0 Connection distance: up to 8 meters Supports Android 3.0 and iOS 4.0 or after Built-in 3.7V rechargeable 45mA battery Power indicator Input DC 5V Full recharge time: 1hr Stand by time: 100hrs MONOPOD Stainless steel Extended max length: 1.04M

PHONE HOLDER

☐ Flexible mount height: 5.5cm - 8.5cm (Max)

Material: ABS and stainless steel

☐ Max weight handled: 230 grams

□ Folded length: 16.8cm

ACCESSORIES:

☐ Adjustable adaptor with universal 1/4 screw lock

 \square Smartphone holder (model A) x 1

☐ Micro USB charging cable

TECHNICAL ASSISTANCE:

If you need assistance with the Aerpro APSSB now or in the future, contact Aerpro Support Australia: www.aerpro.com/Contact

Indentation design along the metal rod to avoid smartphones turning down by weight or movement